



J1-J4	A group of five jumpers determines the port type, NT or TE. If the jumpers short the two pins on the right (default setting), then the port is configured as "TE". If the jumpers connect the two pin on the left, the port is configured as "NT". Please note that a complete set of jumpers must be moved for each port.
D1-D4	The DIP switches are in the "on" position by default . This sets the terminal resistance to 100 Ohm. To change the terminal resistance, set the DIP switches to "off".
PJ1-PJ4	This group of pins must to be closed horizontally for activate power feeding on the port. Thatfore you need to connect a BNPower1 or BNPower2. PJ1 is for Port 1 ...
J-PCI	Jumper for PCI Voltage (3.3V / 5V). Factory default is 3.3V PCI (closed right). This option generates 3.3V out of the 5V from the PCI bus. 3.3Vreg (closed left) uses the 3.3V from the PCI bus (only available in 3.3V PCI slots)
PC1	Powerconnector for the optional available power feeding Module BNPW1. If you are using this, all jumpers auf group PC2 has to be closed horizontally.
PC2	Powerconnector for the optional available onboard power feeding Module BNPW2
PCMout-PCMin	Connectors for the PCM bus. The PCM bus potentiates to bridge calls in hardware across different beroNet cards whcih are connected over the PCM bus.